

●プロトン 対応システム (Ver 2019.02)

システム名	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
ABS	●	●	●	●	●
ABS (MMC)	●	●	●		●
ABS (TEVES MK20)	●	●		●	●
ABS (TEVES MK60)	●	●		●	●
ABS (TRW)	●	●	●	●	●
ABS (ボッシュ)	●	●	●	●	●
ALL (ABS)	●	●	●	●	●
ALL (ABS・ESC)	●	●	●	●	●
ALL (AC)	●	●	●	●	●
ALL (AT)	●	●		●	●
ALL (ATM (TCU))	●	●		●	●
ALL (BCM)	●	●	●	●	●
ALL (EPI)	●	●	●	●	●
ALL (EPS)	●	●			●
ALL (ETACS)	●	●	●	●	●
ALL (SRS)	●	●	●	●	●
ALL (イモビライザー)	●	●	●	●	●
ALL (エンジン (ECU))	●	●	●	●	●
ALL (エンジン)	●	●	●	●	●
ALL (ギアシフトロック)	●	●			●
ALL (トランスミッション)	●	●		●	●
ALL (パワーステアリング)	●	●	●	●	●
ALL (メーター)	●	●	●	●	●
ATM (TCU) (ATM)	●	●	●	●	●
ATM (TCU) (MMC)	●	●	●		●
ATM (TCU) (MMC_ISO)	●	●	●		●
ATM (TCU) (ルノー12)	●	●	●	●	●
EPS (MMC_EPS)	●	●	●		●
SRSエアバッグ (AC3)	●	●		●	●
SRSエアバッグ (エアバッグ)	●	●		●	●

イモビライザー	●	●		●	●
イモビライザー (SIEMENS)	●	●		●	●
エンジン (ECU) (EMS400)	●	●	●	●	●
エンジン (ECU) (EMS700)	●	●	●	●	●
エンジン (ECU) (MMC)	●	●	●		●
エンジン (ECU) (エンジン)	●	●	●	●	●
エンジン (ECU) (ルノー-12)	●	●	●	●	●