

●KIA 対応システム(Ver 2023.10)

システム	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
4WD (4WD Control)	●	●	●	●	●
AAF (Active Air Flap)	●	●	●	-	●
ABS (Anti-Lock Brake)	●	●	●	●	●
ABS/ESC	●	●	●	●	●
ABSESC (ABS/ESC)	●	●	●	●	●
ABSESP (ABS/ESC)	●	●	●	●	●
ABSESP (ABS/ESP)	●	●	●	●	●
ABSVDC (Electronic Stability Control)	●	●	●	●	●
ADAS_DRV (ADAS Driving ECU)	●	●	-	●	●
ADAS_PRK (Advanced Driver Assistance Systems_Parking)	●	●	●	●	●
ADP (Acoustic Design Processor)	●	-	-	-	●
AEB (Assist Emergency Braking System)	●	●	-	●	●
AFCU (Auto Flush handle Control Unit)	●	●	●	-	●
AFLS (Adaptive Front Lighting System)	●	●	●	●	●
AHB (Active Hydraulic Booster)	●	●	●	●	●
AHLS (Auto Headlamp Leveling System)	●	●	●	●	●
AHS (Active Hood System)	●	●	●	●	●
AIRBAG	●	●	-	●	●
AIRCON (Air Conditioner)	●	●	●	-	●
AMP (Amplifier)	-	-	-	●	●
AMT (Automated Manual Transmission)	●	●	●	●	●
APSM (Assist Power Seat Module)	●	●	●	●	●
ARS (Rear Armrest Switch)	●	●	●	●	●
ASM (Assist Door Module)	●	●	●	●	●
AT (Automatic Transaxle)	●	●	●	●	●
AT (Double Clutch Transmission)	●	●	●	●	●
AVN (Audio Video Navigation)	●	●	-	●	●
BCM (Body Control Module)	●	●	●	●	●
BCW (Blind-Spot Collision Warning)	●	●	●	●	●
BCW-L (Blind-Spot Collision Warning-Left)	●	●	●	●	●
BCW-R (Blind-Spot Collision Warning-Right)	●	●	●	●	●
BHEATER (Fuel Fired Heater)	●	●	●	-	-
BMS (HEV Battery System)	●	●	●	●	●
BMS (PHEV Battery Management System)	●	●	●	●	●
BMS (EV Battery System)	●	●	●	●	●
BMS (HEV Battery System)	●	●	●	●	●
BMS (PHEV Battery System)	●	●	●	●	●
BMSLDC (BMS/LDC)	●	●	●	-	●
BSD (Blind Spot Detection)	●	●	●	●	●
BSD-L (Blind Spot Detection-Left)	●	●	●	●	●
BSD-R (Blind Spot Detection-Right)	●	●	●	●	●
C_RADAR (Corner Radar)	●	●	-	●	●
CCM (Charging Control Module)	●	●	-	-	●
CCP (Central Control Panel)	●	-	-	-	●
CDM (Charge Door Module)	●	●	-	-	●
CGW (Central Gateway)	●	-	-	●	●
CLU (Cluster Module)	●	●	●	●	●
CODE (Transmitter Code Saving)	-	●	-	●	-
CUBIS	●	●	-	-	●
CVT (Continuously Variable Transmission)	●	●	●	●	●
DAU (Door Area Unit)	●	●	●	●	●
DDM (Driver Door Module)	●	●	●	●	●
DIS (Multimedia)	●	●	-	-	●
DLBCU (Driver Lumbar Bolster Cushion Unit)	●	●	●	-	●
DPSS (Driver Power Seat Switch)	●	●	-	-	●
DVRS (Drive Video Record System)	●	●	●	●	●
EASM (Electronic Asistant Seat Module (-IMS))	●	●	●	-	●
ECALL (e-Call)	●	●	-	●	●
ECS (Electronic Control Suspension)	●	●	●	●	●
EDSM (Electronic Driver Seat Module (-IMS))	●	●	●	-	●
ELSD (Electronic Limited Slip Differential)	●	●	●	●	●
ENGINE	●	●	●	●	●
ENGINE (EMS ECU (F/L))	●	●	●	●	●
ENGINE (EMS ECU (~2009.05.14))	●	●	●	●	●

●KIA 対応システム (Ver 2023.10)

システム	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
ENGINE (EMS ECU (2009. 05. 15~))	●	●	●	●	●
ENGINE (EMS ECU)	●	●	●	●	●
ENGINE (IFB ECU (F/L))	●	●	●	-	●
ENGINE (IFB ECU (~2009. 05. 14))	●	●	●	-	●
ENGINE (IFB ECU (2009. 05. 15~))	●	●	●	-	●
ENGINE (IFB ECU)	●	●	●	-	●
EPB (Electric Parking Brake)	●	●	●	●	●
EPS (Motor Driven Power Steering)	●	●	●	●	●
ESC (Electronic Stability Control)	●	●	●	●	●
ESCAHB (ESC/AHB)	●	●	●	●	●
ESG (Electronic Sound Generator)	●	-	-	-	●
ESHIFTER (E-Shifter)	●	●	●	●	●
ESHIFTER (SBW)	●	●	●	-	●
ESHIFTER_BS (E-Shifter)	●	●	-	●	●
ESP (Electronic Stability Program)	●	●	●	●	●
ESU (Ethernet Switch Unit)	●	●	-	-	●
ETACS	-	●	●	-	●