

●ヒョンデ 対応システム(Ver 2024.06)

システム名	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
4WD (4WD Control)	●	●	●	●	●
AAF (Active Air Flap)	●	●	●	-	●
AAF-L (Active Air Flap-Left)	●	●	●	-	●
AAF-R (Active Air Flap-Right)	●	●	●	●	●
ABS (Anti-Lock Brake)	●	●	●	●	●
ABSESC (ABS/ESC)	●	●	●	●	●
ABSESP (ABS/ESP)	●	●	●	●	●
ABSVDC (Brake)	●	●	●	●	●
ADAS_DRV (ADAS Driving ECU)	●	●	-	●	●
ADAS_PRK (Advanced Driver Assistance System_Parking)	●	●	-	●	●
ADM (Assist Door Module)	●	●	●	-	●
AEB (Autonomous Emergency Braking System)	●	●	-	●	●
AFCU (Auto Flush-Handle Control Unit)	●	●	●	-	●
AFCU-DRV (Auto Flush-Handle Control Unit-DRV)	●	●	●	-	●
AFCU-PAS (Auto Flush-Handle Control Unit-PAS)	●	●	●	-	●
AFCU-RL (Auto Flush-Handle Control Unit-RL)	●	●	●	-	●
AFCU-RR (Auto Flush-Handle Control Unit-RR)	●	●	●	-	●
AFLS (Adaptive Front Lighting System)	●	●	●	●	●
AGCS (Active Geometry Control Suspension)	●	●	●	-	●
AHB (Active Hydraulic Booster)	●	●	●	●	●
AHLS (Auto Headlamp Leveling System)	●	●	-	●	●
AHS (Active Hood System)	●	●	●	-	●
AIRBAG	●	●	-	●	●
AIRCON (Air Conditioner)	●	●	●	-	●
ALU (Assist Lumbar Unit)	●	●	●	-	●
AMP (Amplifier)	●	●	-	●	●
AMT (Automated Manual Transmission)	●	●	●	●	●
APSM (Assist Power Seat Module)	●	●	●	●	●
APSS (Assist Power Seat Switch)	●	●	-	●	●
APSU (Assist Power Seat Unit)	●	●	-	●	●
ARS (Rear Armrest Switch)	●	●	●	●	●
AT (Automatic Transaxle)	●	●	●	●	●
AT (Double Clutch Transmission)	●	●	●	●	●
AVM (Around View Monitor System)	●	●	●	●	●
AVN (Audio Video Navigation)	-	●	-	●	●
BCM (Body Control Module)	●	●	●	●	●
BCW (Blind-Spot Collision Warning)	●	●	●	●	●
BCW-L (Blind-Spot Collision Warning-Left)	●	●	●	●	●
BCW-R (Blind-Spot Collision Warning-Right)	●	●	●	●	●
BHDC (Bi-directional High DC/DC Converter)	●	●	-	-	●
BHEATER (Fuel Fired Heater)	●	●	●	-	-
BMS (PHEV Battery System)	●	●	●	-	●
BMS (Battery Management System)	●	●	●	●	●
BMS (EV Battery System)	●	●	●	●	●
BMS (HEV Battery System)	●	●	●	●	●
BMS (PHEV Battery System)	●	●	●	●	●
BMSLDC (BMS/LDC)	●	●	●	-	●
BPCU (Blower Pump Control Unit)	●	●	-	-	●
BSD (Blind Spot Detection)	●	●	●	●	●
BSD-L (Blind Spot Detection-Left)	●	●	●	●	●
BSD-R (Blind Spot Detection-Right)	●	●	●	●	●
C_RADAR (Corner Radar)	●	●	●	●	●
CCM (Charging Control Module)	●	●	-	-	●
CCP (Central Control Panel)	●	-	-	-	●
CDM (Charge Door Module)	●	●	-	-	●
CDP (CD Player)	●	-	●	-	●
CGW (Central Gateway)	●	●	-	●	●
CLU (Cluster Module)	●	●	●	●	●
CLU_VC (Cluster Variant Coding)	●	-	-	●	●
CODE (Transmitter Code Saving)	-	●	-	●	-

●ヒョンデ 対応システム(Ver 2024.06)

システム名	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
CRUISE (Cruise Control)	●	-	-	-	-
CUBIS	●	●	-	-	●
CVT (Continuously Variable Transmission)	●	●	●	●	●
DAU (Door Area Unit)	●	●	●	●	●
DDM (Driver Door Module)	●	●	●	●	●
DHSM-FL (Door Handle Sensor Module-Front Left)	●	●	●	-	●
DHSM-FR (Door Handle Sensor Module-Front Right)	●	●	●	-	●
DIS (Multimedia)	●	●	-	●	●
DLBCU (Driver Lumbar Bolster Cushion Unit)	●	●	●	-	●
DPSS (Driver Power Seat Switch)	●	●	-	-	●
DSM_L (Digital Side Mirror-Left)	●	●	●	-	-
DSM_R (Digital Side Mirror-Right)	●	●	●	-	-
DSS (Driver Seat Switch)	●	●	-	-	●
DTGDIS (Digital Tachograph)	●	-	-	-	●
DVRS (Drive Video Record System)	●	●	●	-	●
ECALL	●	●	-	●	●
ECS (Electronic Control Suspension)	●	●	●	●	●
ECW (Electric Control Wiper)	●	●	-	-	●
ELSD (Electronic Limited Slip Differential)	●	●	●	●	●
ENGINE	●	●	●	●	●
ENGINE (EMS ECU)	●	●	●	●	●
Engine (EMS)	●	●	●	●	●
Engine (EMS:F/L)	●	●	●	●	●
Engine (EMS:Older)	●	●	●	●	●
ENGINE (IFB ECU)	●	●	●	-	●
Engine (IFB)	●	●	●	-	●
Engine (IFB:F/L)	●	●	●	-	●
Engine (IFB:Older)	●	●	●	-	●
Engine (Integrated)	●	●	●	●	●
EPB (Electric Parking Brake)	●	●	●	●	●
EPS (Electronic Power Steering)	●	●	●	●	●
EPS (Motor Driven Power Steering)	●	●	●	●	●
EPS (Power Steering)	●	●	-	●	●
ESC (Electronic Stability Control)	●	●	●	●	●
ESCAHB (ESC/AHB)	●	●	●	●	●
ESG (Electronic Sound Generator)	●	-	-	-	●
ESHIFTER (E-Shifter)	●	●	●	-	●
ESHIFTER_BS (E-Shifter)	●	●	●	-	●
ESP (Electronic Stability Program)	●	●	●	●	●
ESPAHB (ESP/AHB)	●	●	●	●	●
ESU (Ethernet Switch Unit)	●	●	-	-	●
ETACS	●	-	●	-	●
FAM (Front Area Module)	●	●	●	●	●
FBWS (Front Back Warning System)	●	●	-	-	●
FCA (Forward Collision-Avoidance Assist)	●	●	-	●	●
FCU (Fuel Cell System)	●	●	●	●	●
FPD (Fuel Processing Driver)	●	●	●	-	●
FPM (Finger Print Module)	●	●	-	●	●
FR_CMR (Front View Camera)	●	●	-	●	●
FR_CMR (Multi Function Camera)	●	●	-	●	●
FR_RADAR (Front Radar)	●	●	-	●	●
FSJB (Front Back Warning System)	●	●	-	-	●
HCU (HEV Control System)	●	●	●	●	●
HCULDC (HCU/Low DC-DC Converter)	●	●	●	●	●

●ヒョンデ 対応システム(Ver 2024.06)

システム名	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
HDC (High DC/DC Converter)	●	●	-	-	●
HEADUNIT (Head Unit)	●	●	●	●	●
HMU (Hydrogen storage system Management Unit)	●	●	●	●	●
HSCU (Hydrogen Storage System)	●	●	●	●	●
HSWS (Haptic Steering-Wheel Warning System)	●	-	-	-	●
HUD (Head Up Display)	●	●	-	●	●
IAP (Intelligent Accel Pedal)	●	●	●	-	●
IAU (Identity Authentication Unit)	●	●	-	●	●
I-BOX	●	-	-	-	●
IBU-BCM (IBU-Body Control Module)	●	●	●	●	●
IBU-BCM (Integrated Body Control Unit)	●	●	●	●	●
IBU-BCM (Integrated Body Control Unit-BCM)	●	●	●	●	●
IBU-IMMO (IBU-Immobilizer)	●	●	-	●	-
IBU-IMMO (Integrated Body Control Unit)	●	●	-	●	-
IBU-IMMO (Integrated Body Control Unit-IMMO)	●	●	-	●	-
IBU-SMK (IBU-Smart Key Unit)	●	●	●	●	●
IBU-SMK (Integrated Body Control Unit)	●	●	●	●	●
IBU-SMK (Integrated Body Control Unit-SMK)	●	●	●	●	●
IBU-TPMS (IBU-Tire Pressure Monitoring System)	●	●	-	●	●
IBU-TPMS (Integrated Body Control Unit)	●	●	-	●	●
IBU-TPMS (Integrated Body Control Unit-TPMS)	●	●	-	●	●
ICCU (Integrated Charging Control Unit)	●	●	-	-	●
ICU (Integrated Central Control Unit)	●	●	●	●	●
IFU (Interface Unit)	●	●	●	●	●
IGPM (Integrated Gateway Power Control Module)	●	●	●	●	●
ILCU-LH (Integrated Led healamp Control Unit_LH)	●	●	●	●	●
ILCU-RH (Integrated Led healamp Control Unit_RH)	●	●	●	●	●
IMMO (Immobilizer)	●	●	-	●	-
IMS (Integrated Memory System)	●	●	●	-	●
IMT (Intelligent Manual Transmission)	●	●	-	●	●
IPM (Instrument Panel Module)	●	●	●	●	●
LAN	●	●	●	●	●
LDC (Low DC/DC Converter)	●	●	-	-	●
LDWS (Lane Departure Warning System)	●	●	●	●	●
LKA (Lane Keeping Assist)	●	●	-	●	●
LKAS (Lane Keeping Assist System)	●	●	-	●	●
MCA (Modular Clutch Actuator)	●	●	●	●	●
MCS (Multi-View Camera System)	●	●	●	●	●
MCU (PHEV Motor Control System)	●	●	●	-	●
MCU (EV Motor Control System)	●	●	●	●	●
MCU (HEV Motor Control System)	●	●	●	●	●
MCU (Motor Control System)	●	●	-	●	●
MCU (PHEV Motor Control System)	●	●	●	●	●
MCU_F (Motor Control Unit-Front)	●	●	●	●	●
MCU_R (Motor Control Unit-Rear)	●	●	●	●	●
MFC (Multi Function Camera)	●	●	●	●	●
MFSW (Multi Function Switch)	●	●	-	-	●
MLM (Mood Lamp Module)	●	●	●	-	●
M-MEDIA (Multimedia)	●	●	-	●	●
MOZEN	●	-	-	●	●
OBC (On Board Charger)	●	●	-	●	●
OCS (Occupant Classification System)	●	●	-	●	●
ODS (Occupant Detection Sensor)	●	●	-	●	●
ODS (Occupant Detection System)	●	●	-	●	●

●ヒョンデ 対応システム(Ver 2024.06)

システム名	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
OPTION (User Option)	-	●	-	●	-
PA (Parking Assist)	●	●	-	●	●
PCM (Powerline Communication Module)	●	●	-	-	●
PDM (Power Distribution Module)	●	●	●	●	●
PFSU (Power Folding Seat Unit)	●	●	●	●	●
PGS (Dynamic Guideline Camera)	●	●	-	●	●
PGS (Parking Guide System)	●	●	●	●	●
PSB (Pre-safe Seat Belt)	●	●	●	●	●
PSB-L (Pre-safe Seat Belt-Left)	●	-	●	●	●
PSB-R (Pre-safe Seat Belt-Right)	●	-	●	●	●
PSD (Power Sliding Door)	●	●	●	●	●
PSD-L	●	●	-	-	●
PSD-R	●	●	-	-	●
PSM (Power Seat Module)	●	●	●	●	●
PSM-RL (Power Seat Module-Rear Left)	●	●	●	●	●
PSM-RR (Power Seat Module-Rear Right)	●	●	●	●	●
PTG (Power Tail Gate)	●	●	●	●	●
PTM (Power Trunk Module)	●	●	●	●	●
RADFAN-L (Radiator Fan-Left)	●	●	●	-	●
RADFAN-R (Radiator Fan-Right)	●	●	●	-	●
RAM	●	●	●	-	●
RARS (Rear Armrest Switch)	●	●	-	-	●
RDC (Rear Door Curtain)	●	●	●	●	●
RLHVV (Rear Left Heater Ventilation Unit)	●	●	●	-	●
RLPSU (Rear Left Power Seat Unit)	●	●	●	●	●
ROA (Rear Occupant Alert)	●	●	-	-	●
ROA (Rear Oxxupant Alert)	●	●	-	-	●
RR_C_RADAR (Corner Radar)	●	●	-	●	●
RR_C_RADAR (Rear Corner Radar)	●	●	●	●	●
RR_C_RADAR_L (Rear Corner Radar-Left)	●	●	●	●	●
RR_C_RADAR_R (Rear Corner Radar-Right)	●	●	●	●	●
RRC (Rear Remote Controller)	●	-	-	-	●
RRHVV (Rear Right Heater Ventilation Unit)	●	●	●	-	●
RRPSU (Rear Right Power Seat Unit)	●	●	●	●	●
RSPA (Remote Smart Parking Assist)	●	●	-	●	●
RVM (Rear View Monitor)	●	●	-	●	●
RWPC (Rear Wireless Power Charger)	●	●	-	●	●
RWS (Rear Wheel Steering)	●	●	-	-	●
SCC (Smart Cruise Control)	●	●	-	●	●
SCCAEB (SCC/AEB)	●	●	-	●	●
SCM (Steering Column Module)	●	●	●	●	●
SCR (Selective Catalytic Reduction)	●	●	●	●	●
SCU (SBW Control Unit (SCU))	●	●	●	●	●
SDC (Solar DCDC Converter)	●	●	-	●	●
SERVICE (Service Reminder)	-	-	-	●	●
SHVV (Seat Heater Ventilation Control Unit)	●	●	●	-	●
SHVV-F (Seat heater Ventilation control Unit-Front)	●	●	●	-	●
SHVV-R (Seat heater Ventilation control Unit-Rear)	●	●	●	●	●
SJB (Smart Junction Block)	●	●	●	●	●
SLB (Seat Lumbar Bolster)	●	●	●	-	●
SLM (Seat Belt Reminder/Lighting Module)	●	●	●	-	●
SMK (Smart Key Unit)	●	●	●	●	●
SMKCODE (Smart Key Code Saving)	-	●	-	●	-
SPAS (Smart Parking Assist System)	●	●	●	●	●

●ヒョンデ 対応システム(Ver 2024.06)

システム名	自己診断	データ表示	アクティブテスト	作業サポート	識別情報表示
SVM (Stack Volt Monitor)	●	●	-	-	●
SVMS (Surround View Monitor)	●	●	●	●	●
SWRC (Steering Wheel Remote Control)	●	●	-	-	●
TCS (Traction Control System)	●	●	●	●	●
TILT (Tilt/Telescope)	●	●	●	-	●
TMU (Telematics Unit)	●	-	-	-	●
TPMS (Tire Pressure Monitoring System)	●	●	●	●	●
TUNER_AMP (Tuner/Amplifier)	●	-	-	●	●
TV	●	-	-	●	●
VCMS (Vehicle Charging Management System)	●	●	-	●	●
VCU (Vehicle Control System)	●	●	●	●	●
VCULDC	●	●	●	●	●
VDC (Vehicle Dynamic Control)	●	●	●	●	●
VDCAHB (Brake)	●	●	●	●	●
VESS (Virtual Engine Sound System)	●	-	●	-	●
VRS (Voice Recognition System)	●	-	-	●	●
WPC (Wireless Power Charger)	●	●	●	-	●