

●マヒンドラ 作業サポート (Ver 2024.06)

システム名	項目名
EMS (ENGINE MANAGEMENT SYSTEM)	Adaptives after regeneration particle filter
EMS (ENGINE MANAGEMENT SYSTEM)	Adaptives after replacing cabin filter
EMS (ENGINE MANAGEMENT SYSTEM)	Air Bleeding
EMS (ENGINE MANAGEMENT SYSTEM)	Airbag
EMS (ENGINE MANAGEMENT SYSTEM)	Battery reset
EMS (ENGINE MANAGEMENT SYSTEM)	Cabin filter regeneration
EMS (ENGINE MANAGEMENT SYSTEM)	Check target teeth
EMS (ENGINE MANAGEMENT SYSTEM)	Clear Learned Data In EEPROM
EMS (ENGINE MANAGEMENT SYSTEM)	DPF Regeneration
EMS (ENGINE MANAGEMENT SYSTEM)	DPF Reset
EMS (ENGINE MANAGEMENT SYSTEM)	EGR value
EMS (ENGINE MANAGEMENT SYSTEM)	EGR valve programming
EMS (ENGINE MANAGEMENT SYSTEM)	EVGT EEPROM OFFSET LEARNING
EMS (ENGINE MANAGEMENT SYSTEM)	Gear EOL Endpoint Adaptation
EMS (ENGINE MANAGEMENT SYSTEM)	Immobiliser ECU Programming
EMS (ENGINE MANAGEMENT SYSTEM)	Immobilizer
EMS (ENGINE MANAGEMENT SYSTEM)	Inlet metering valve
EMS (ENGINE MANAGEMENT SYSTEM)	Key Assignment
EMS (ENGINE MANAGEMENT SYSTEM)	Learn single RKE
EMS (ENGINE MANAGEMENT SYSTEM)	Locking with key
EMS (ENGINE MANAGEMENT SYSTEM)	N Position Self-Learning
EMS (ENGINE MANAGEMENT SYSTEM)	Number Of Service Done
EMS (ENGINE MANAGEMENT SYSTEM)	Overspeed alarm for arabia
EMS (ENGINE MANAGEMENT SYSTEM)	Radio frequency function
EMS (ENGINE MANAGEMENT SYSTEM)	Read Configuration
EMS (ENGINE MANAGEMENT SYSTEM)	Read IQA Code
EMS (ENGINE MANAGEMENT SYSTEM)	Start Stop Counters
EMS (ENGINE MANAGEMENT SYSTEM)	Write C3I Values
EMS (ENGINE MANAGEMENT SYSTEM)	Write IQA Code
EMS (ENGINE MANAGEMENT SYSTEM)	Write IQA Values
EMS (ENGINE MANAGEMENT SYSTEM)	Write Parameter
EMS (ENGINE MANAGEMENT SYSTEM)	Write transmission oil change date
EMS (ENGINE MANAGEMENT SYSTEM)	Write tuner region
EMS (ENGINE MANAGEMENT SYSTEM)	Write Variant Code
EMS (ENGINE MANAGEMENT SYSTEM)	Write VIN
EMS (ENGINE MANAGEMENT SYSTEM)	DPF Service Regeneration
EMS (ENGINE MANAGEMENT SYSTEM)	DPF Reset
EMS (ENGINE MANAGEMENT SYSTEM)	Reset DEF Tank Level
EMS (ENGINE MANAGEMENT SYSTEM)	Write EVGT
EMS (ENGINE MANAGEMENT SYSTEM)	SCR AutoEOL Status
EMS (ENGINE MANAGEMENT SYSTEM)	Reset SCR First Filling Status
EMS (ENGINE MANAGEMENT SYSTEM)	Reset SCR Inducement - 50 Kms distance extension
EMS (ENGINE MANAGEMENT SYSTEM)	SCR NH3 Initialization Load Value
EMS (ENGINE MANAGEMENT SYSTEM)	SDPF Change
EMS (ENGINE MANAGEMENT SYSTEM)	Dosing Module / Supply Pump Change
EMS (ENGINE MANAGEMENT SYSTEM)	DPS Learning Reset
EMS (ENGINE MANAGEMENT SYSTEM)	First Filling Test
EMS (ENGINE MANAGEMENT SYSTEM)	Emptying of SCR System
EMS (ENGINE MANAGEMENT SYSTEM)	Pressure Preparation Test
EMS (ENGINE MANAGEMENT SYSTEM)	DEF Leak Test
EMS (ENGINE MANAGEMENT SYSTEM)	Dosing Valve Dry Actuation Test
EMS (ENGINE MANAGEMENT SYSTEM)	DEF Backflow Pump Test
EMS (ENGINE MANAGEMENT SYSTEM)	DEF Metered Dosing Test
EMS (ENGINE MANAGEMENT SYSTEM)	DEF Static Dosing Test
EMS (ENGINE MANAGEMENT SYSTEM)	DEF Dynamic Dosing Test
EMS (ENGINE MANAGEMENT SYSTEM)	DEF Dosing Module Spray Test
EMS (ENGINE MANAGEMENT SYSTEM)	SCR Auto EOL Test
EMS (ENGINE MANAGEMENT SYSTEM)	DNOX53 SCR First Filling Test
EMS (ENGINE MANAGEMENT SYSTEM)	DNOX53 SCR Pressure Preparation Test
EMS (ENGINE MANAGEMENT SYSTEM)	DNOX53 SCR Emptying Test
EMS (ENGINE MANAGEMENT SYSTEM)	DNOX53 SCR Leak Detection Test
EMS (ENGINE MANAGEMENT SYSTEM)	DNOX53 SCR Dosing Valve Dry Actuation Test
EMS (ENGINE MANAGEMENT SYSTEM)	DNOX53 SCR Dosing Accuracy Test

●マヒンドラ 作業サポート (Ver 2024.06)

システム名	項目名
EMS (ENGINE MANAGEMENT SYSTEM)	DNOX53 SCR Auto EOL Test
ABS (ANTI-LOCK BRAKING SYSTEM)	Air Bleeding
ABS (ANTI-LOCK BRAKING SYSTEM)	EHCUC Bleeding
ABS (ANTI-LOCK BRAKING SYSTEM)	Erase Pressure regulation adaptives
ABS (ANTI-LOCK BRAKING SYSTEM)	Gear EOL Synch Start Adaptation
ABS (ANTI-LOCK BRAKING SYSTEM)	Input Signal Feature
ABS (ANTI-LOCK BRAKING SYSTEM)	Longitudinal Acceleration Sensor Calibration
ABS (ANTI-LOCK BRAKING SYSTEM)	Repair Bleeding
ABS (ANTI-LOCK BRAKING SYSTEM)	Steering Angle Sensor Calibration
ABS (ANTI-LOCK BRAKING SYSTEM)	Write VIN
MBFM (MAHINDRA BODY FUNCTION MODULE)	Clutch Position Offset Adaptation
MBFM (MAHINDRA BODY FUNCTION MODULE)	Engine type
MBFM (MAHINDRA BODY FUNCTION MODULE)	Erase EGR adaptives
MBFM (MAHINDRA BODY FUNCTION MODULE)	Fan high speed relay
MBFM (MAHINDRA BODY FUNCTION MODULE)	Feature Coding
MBFM (MAHINDRA BODY FUNCTION MODULE)	Fuel Supply Prevention
MBFM (MAHINDRA BODY FUNCTION MODULE)	Gear EOL Spitout Adaptation
MBFM (MAHINDRA BODY FUNCTION MODULE)	Gear EOL Xgate Valve Adaptation
MBFM (MAHINDRA BODY FUNCTION MODULE)	Glow plug relay
MBFM (MAHINDRA BODY FUNCTION MODULE)	Learn double RKE
MBFM (MAHINDRA BODY FUNCTION MODULE)	Learn single RKE
MBFM (MAHINDRA BODY FUNCTION MODULE)	MBFM Configuration
MBFM (MAHINDRA BODY FUNCTION MODULE)	Monitoring Parameters
MBFM (MAHINDRA BODY FUNCTION MODULE)	Particle filter relative pressure sensor
MBFM (MAHINDRA BODY FUNCTION MODULE)	RDS parameter
MBFM (MAHINDRA BODY FUNCTION MODULE)	Read Configuration
MBFM (MAHINDRA BODY FUNCTION MODULE)	RKE Learn
MBFM (MAHINDRA BODY FUNCTION MODULE)	RKE LEARNING
MBFM (MAHINDRA BODY FUNCTION MODULE)	Vehicle Config - From Variant Present
MBFM (MAHINDRA BODY FUNCTION MODULE)	Vehicle Config - Manual Setting
MBFM (MAHINDRA BODY FUNCTION MODULE)	VIN Write
MBFM (MAHINDRA BODY FUNCTION MODULE)	Write VIN
SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	Auto adaptives
SRS (SUPPLEMENTARY RESTRAINT SYSTEM)	Write Data Identifier
TCU (TRANSMISSION CONTROL UNIT)	Air damper valve programming
TCU (TRANSMISSION CONTROL UNIT)	Air Venting
TCU (TRANSMISSION CONTROL UNIT)	Compression test
TCU (TRANSMISSION CONTROL UNIT)	Configuration
TCU (TRANSMISSION CONTROL UNIT)	Configuration privee 31
TCU (TRANSMISSION CONTROL UNIT)	Courtesy light timer
TCU (TRANSMISSION CONTROL UNIT)	Crash Status
TCU (TRANSMISSION CONTROL UNIT)	De-ice function
TCU (TRANSMISSION CONTROL UNIT)	Delete Key
TCU (TRANSMISSION CONTROL UNIT)	EMS ECU Programming
TCU (TRANSMISSION CONTROL UNIT)	Fan low speed relay
IC (INSTRUMENT CLUSTER)	Feature Coding
IC (INSTRUMENT CLUSTER)	Hydraulic test
IC (INSTRUMENT CLUSTER)	Illuminate hazard lamps upon impact
IC (INSTRUMENT CLUSTER)	Particle filter relative pressure sensor
IC (INSTRUMENT CLUSTER)	Read Configuration
IC (INSTRUMENT CLUSTER)	Read Odometer
IC (INSTRUMENT CLUSTER)	Read VIN
IC (INSTRUMENT CLUSTER)	Service reminder
IMMO (IMMOBILISER)	Originally fitted perimetric protection
IMMO (IMMOBILISER)	Particle filter relative pressure sensor
IMMO (IMMOBILISER)	Read Configuration
IMMO (IMMOBILISER)	Write Model Number
FATC (FULLY AUTOMATED TEMPERATURE CONTROL)	Write Variant Code
FATC (FULLY AUTOMATED TEMPERATURE CONTROL)	Write VIN
IS (INFOTAINMENT SYSTEM)	Engine Adaptives
IS (INFOTAINMENT SYSTEM)	Gear EOL Clutch Valve Adaptation
IS (INFOTAINMENT SYSTEM)	Interval variation with speed
IS (INFOTAINMENT SYSTEM)	Learn Key

●マヒンドラ 作業サポート (Ver 2024.06)

システム名	項目名
IS (INFOTAINMENT SYSTEM)	Lock injector control
IS (INFOTAINMENT SYSTEM)	Longitudinal Acceleration Sensor Calibration
IS (INFOTAINMENT SYSTEM)	Originally fitted perimetric protection
IS (INFOTAINMENT SYSTEM)	Particle filter relative pressure sensor
IS (INFOTAINMENT SYSTEM)	Pressure regularion adaptives
IS (INFOTAINMENT SYSTEM)	Radio frequency function
IS (INFOTAINMENT SYSTEM)	Raid function authorisation by diag
IS (INFOTAINMENT SYSTEM)	RDS parameter
IS (INFOTAINMENT SYSTEM)	Read Configuration
IS (INFOTAINMENT SYSTEM)	Write Owner's Name
VCT (VOICE COMMAND TECHNOLOGY)	EHCUC Bleeding
VCT (VOICE COMMAND TECHNOLOGY)	Exhaust injector circuit
VCT (VOICE COMMAND TECHNOLOGY)	Read Configuration
ESP (ELECTRONIC STABILITY PROGRAM)	Erase Pressure regulation adaptives
ESP (ELECTRONIC STABILITY PROGRAM)	Gear EOL Synch Start Adaptation
ESP (ELECTRONIC STABILITY PROGRAM)	Heated rear screen when driving
ESP (ELECTRONIC STABILITY PROGRAM)	Input Signal Feature
ESP (ELECTRONIC STABILITY PROGRAM)	Longitudinal Acceleration Sensor Calibration
EPS (ELECTRONIC POWER STEERING)	Input Signal Feature
EPS (ELECTRONIC POWER STEERING)	Particle filter relative pressure sensor
EPS (ELECTRONIC POWER STEERING)	Read Configuration
EPS (ELECTRONIC POWER STEERING)	Steering Angle Sensor Calibration
Gasoline	Read IQA Code
Gasoline	Read Odometer
Gasoline	Read VIN
Gasoline	Replacing of the Particulate Filter
Gasoline	RKE LEARNING
Gasoline	S Frame
Gasoline	SAS calibration
Gasoline	Seat belt unfastened detection
Gasoline	Second fitting alarm
Gasoline	Service Done
Gasoline	Service reminder
Gasoline	Starter relay control test
Gasoline	Starter relay request
Gasoline	Static injector learning process
Gasoline	Steering Angle Sensor Calibration
Gasoline	Throttle Valve
Injection	Read IQA Code
Injection	Read Odometer
Injection	Read VIN
Injection	Replacing of the Particulate Filter
Injection	RKE LEARNING
Injection	S Frame
Injection	SAS calibration
Injection	Seat belt unfastened detection
Injection	Second fitting alarm
Injection	Service Done
Injection	Service reminder
Injection	Starter relay control test
Injection	Starter relay request
Injection	Static injector learning process
Injection	Steering Angle Sensor Calibration
Injection	Throttle Valve
UCH	Remote Learn
UCH	RKE Learn
UCH	Speed Index
UCH	Unlock ECU
UCH	Vehicle Config - From Variant Present
UCH	Vehicle Config - Manual Setting
UCH	vehicle locked by autolock when driving
UCH	Vehicle parameters
UCH	Verrou logiciel (software lock)

●マヒンドラ 作業サポート (Ver 2024.06)

システム名	項目名
UCH	VIN Write
UCH	VMS alert
UCH	Write C3I Values
UCH	Write configuration
UCH	Write Data Identifier
UCH	Write Date of Last After Sales Operation
UCH	Write E-Call Number
UCH	Write Engine Serial Number
UCH	Write EVGT
UCH	Write feature code
UCH	Write IQA
UCH	Write IQA Code
UCH	Write IQA Values
UCH	Write mode number
UCH	Write Model No
GAS Injection	Steering Angle Sensor Calibration
GAS Injection	Turbo charger / VGT
Automatic Gearbox	Unlock Computer
Automatic Gearbox	Write Model Number
Automatic Gearbox	Write Owner's Name
A. B. S.	Repair Bleeding
A. B. S.	Reset DEF Tank Level
A. B. S.	Stop Fuel Supply Prevention
A. B. S.	TPMS option
A. B. S.	Unlock Computer
Variable P. A. S.	Unlock Computer
Airbag / Pretensioners	RKE Learn
Airbag / Pretensioners	Start Stop Counters
Airbag / Pretensioners	Timer courtesy light
EMS_UDS_MDG_BSVI	MAF - Air Flow Sensor
EMS_UDS_MDG_BSVI	MBFM Configuration
EMS_UDS_MDG_BSVI	MBFM Feature
EMS_UDS_MDG_BSVI	Monitoring Parameters
UDS_DCM7_1	Monitoring Parameters
UDS_DCM7_1	Number Of Service Done
UDS_DCM7_1	Odo Meter
ENGINE (Mahindra Commercial)	Gear EOL Endpoint Adaptation
ENGINE (Mahindra Commercial)	Learn single RKE
ENGINE (Mahindra Commercial)	Locking with key
ENGINE (Mahindra Commercial)	N Position Self-Learning
ENGINE (Mahindra Commercial)	Radio frequency function
ENGINE (Mahindra Commercial)	Read Configuration
ENGINE (Mahindra Commercial)	Reset ECU
SECURITY SYSTEM - EMS	Key type
SECURITY SYSTEM - EMS	Read Configuration
SECURITY SYSTEM - IMMOBILIZER	Automatic Relocking
SECURITY SYSTEM - IMMOBILIZER	Central locking button type
SECURITY SYSTEM - IMMOBILIZER	EGR Valve
SECURITY SYSTEM - IMMOBILIZER	EKP And Counter Reset
SECURITY SYSTEM - IMMOBILIZER	Enter injector codes
SECURITY SYSTEM - IMMOBILIZER	GNS relay test
SECURITY SYSTEM - IMMOBILIZER	Read Configuration
SECURITY SYSTEM - IMMOBILIZER	Key Assignment
SECURITY SYSTEM - IMMOBILIZER	Reading Immobilizer Password
SECURITY SYSTEM - IMMOBILIZER	Reading EMS Password
ECU FLASHING	ECU Flashing
ECU FLASHING	Write Model No
ECU FLASHING	Write VIN
AMT (AUTOMATED MANUAL TRANSMISSION)	Clutch Position Opened Autolearned Reset
AMT (AUTOMATED MANUAL TRANSMISSION)	Reset Statistical CountersPurge Clutch
AMT (AUTOMATED MANUAL TRANSMISSION)	Depressurization Accumulators
AMT (AUTOMATED MANUAL TRANSMISSION)	Kiss Point Clutch Self Tuning

●マヒンドラ 作業サポート (Ver 2024.06)

システム名	項目名
AMT (AUTOMATED MANUAL TRANSMISSION)	Self Tuning Grids
AMT (AUTOMATED MANUAL TRANSMISSION)	New Actuators
AMT (AUTOMATED MANUAL TRANSMISSION)	Clear Data Group_Replacement Clutch Group
AMT (AUTOMATED MANUAL TRANSMISSION)	Clear Data Group_Replacement Kit
AMT (AUTOMATED MANUAL TRANSMISSION)	Clear Data Group_Replacement Gearbox
AMT (AUTOMATED MANUAL TRANSMISSION)	Clear Data Group_Replacement Lever
AMT (AUTOMATED MANUAL TRANSMISSION)	Clear Data Group_Replacement Pump
AMT (AUTOMATED MANUAL TRANSMISSION)	Clear Data Group_Replacement Accumulator
AMT (AUTOMATED MANUAL TRANSMISSION)	Clear Data Group_Reset Statistics Data
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_Neutral
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_1st Gear
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_2nd Gear
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_3rd Gear
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_4th Gear
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_5th Gear
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_6th Gear
AMT (AUTOMATED MANUAL TRANSMISSION)	Gearbox Shifting_Reverse
AMT (AUTOMATED MANUAL TRANSMISSION)	Clutch Stroke