

●ジャガー 作業サポート(Ver 2024.10)

システム名	項目名
ABS (ABS Control Module)	Parking brake pad replacement – Release to service position
ABS (ABS Control Module)	Parking brake pad replacement – Exit maintenance mode application
ABS (ABS Control Module)	Parking brake activation
ABS (ABS Control Module)	Brake bleed
ABS (ABS Control Module)	Yaw rate sensor calibration
ABS (ABS Control Module)	Lateral accelerometer calibration
ABS (ABS Control Module)	Pressure sensor calibration
BCM (Body Control Module)	Battery Replacement
BCMB (Body Control Module B)	Battery Replacement
CHCM (Chassis Control Module)	Set/Un-set air suspension manufacturing/freeze mode
CHCM (Chassis Control Module)	Set/Un-set air suspension geometry set-up
CHCM (Chassis Control Module)	Set/Un-set air suspension tight tolerance mode (headlamp setting)
CHCM (Chassis Control Module)	Air-suspension deflation
CHCM (Chassis Control Module)	Air-suspension inflation
GWM (Gateway Module)	Battery Replacement – Main Battery
GWM (Gateway Module)	Battery Replacement – Second Battery
GWM (Gateway Module)	Battery Replacement – Both Battery
GWM (Gateway Module)	Battery Replacement
IPC (Instrument Cluster Control Module)	Service Interval Reset
PBM (Parking Brake Control Module)	Parking brake pad replacement – Release to service position
PBM (Parking Brake Control Module)	Parking brake pad replacement – Exit maintenance mode application
PBM (Parking Brake Control Module)	Parking brake activation
PBM (Parking Brake Control Module)	Longitudinal accelerometer calibration
PBM (Parking Brake Control Module)	Parking brake release to the service position
PCM (Powertrain Control Module)	Oil Service Counter reset
PCM (Powertrain Control Module)	Diesel particulate filter replacement
PCM (Powertrain Control Module)	Diesel particulate filter fuel related component replacement
PCM (Powertrain Control Module)	Diesel Particulate Filter Dynamic Regeneration
PCM (Powertrain Control Module)	Fuel Lift Pump
PCM (Powertrain Control Module)	Service Interval Reset
PCM (Powertrain Control Module)	Reset Selective Catalyst Reduction (SCR) Start Inhibit
PCM (Powertrain Control Module)	Fuel Prime Routine
PCM (Powertrain Control Module)	Service Message Reset

●ジャガー 作業サポート(Ver 2024.10)

システム名	項目名
-------	-----